

## SPIN 1.5 VERSION 2

Part #SPIN1.5V2



### Description

Use Profurl's SPIN KIT to turn NEX furlers into asymmetric spinnaker furlers. SPIN KIT includes anti-twist cable, soft sleeves, and upper and lower end fittings; By fitting a SPINKIT on a NEX furler, you get a SPINEX

How it works?  
SPINEX is dedicated to

### Technical description

Why choose SPINEX?  
Easy to use, safe, efficient, adaptable  
Using asymmetric spinnakers in some conditions can be dangerous. With the Spinex, you're going to rediscover the joys of this type of sailing because it allows you to:

- Easily handle this type of Weight: swivel tack point, lower thimble: 0.620 Kg  
Weight: upper thimble: 0.170 Kg  
Weight: cable & sleeve per meter: 0.210 Kg / m

### Components

Anti-torque cables, sleeves, thimbles and swivel tack point



### Technical information

|                             |          |        |       |
|-----------------------------|----------|--------|-------|
| Sailing program             | Cruising | C (mm) | 87    |
| Light sail area (m²)        | 100      | D (mm) | 35    |
| Structural system           | No       | E (mm) | 139.5 |
| Partial furling of the sail | No       | F (mm) | 37    |
| Working load                | 1500     | G (mm) | 21    |
| A (mm)                      | 120.7    | H (mm) | 8.3   |
| B (mm)                      | 80.2     | I (mm) | 10    |