

SPIN 8.0 VERSION 2

Part #SPIN8.0V2



Description

Use Profurl's SPIN KIT to turn NEX furlers into asymmetric spinnaker furlers. SPIN KIT includes anti-twist cable, soft sleeves, and upper and lower end fittings; By fitting a SPINKIT on a NEX furler, you get a SPINEX

How it works?

SPINEX is dedicated to

Technical description

Why choose SPINEX?

Easy to use, safe, efficient, adaptable

Using asymmetric spinnakers in some conditions can be dangerous. With the Spinex, you're going to rediscover the joys of this type of sailing because it allows you to:

- Easily handle this type of Weight: swivel tack point, lower thimble: 1.880 Kg

Weight: upper thimble: 0.590 Kg

Weight: cable & sleeve per meter : 0.500 Kg / m

Components

Anti-torque cables, sleeves, thimbles and swivel tack point



Technical information

Sailing program	Cruising	D (mm)	56.4
Light sail area (m²)	400	E (mm)	216
Structural system	No	F (mm)	60
Partial furling of the sail	No	G (mm)	33
Working load	8000	H (mm)	14.3
B (mm)	160	I (mm)	18
C (mm)	126		